# **FUJIKURA COMPOSITES**

## "FCAM' series



Cracking pressure adjustment model. Corresponds to compressed air and liquid.

#### Features

-Adjustment of cracking pressure is possible.

-High pressure model (maximum working pressure: 20 MPa[2900.75psi]).

- -Ideal for small-volume applications such as prototype, research, etc.
- -Compact, lightweight design.



-Machine Tools : Milling machine, NC lathe, laser processing machine etc.

- -Industrial furnace : General industrial furnace, heating furnace, vacuum furnace, etc.
- -Medical : Endoscope washing device, oxygen concentrator, anesthesia machine etc.
- -Analysis equipment: Measurement equipment, component gas analysis, gas analyzer etc.
- -Battery : Household fuel cell, secondary battery, gas engine etc.
- -Water (liquid) treatment: Pure water production, pure water recycling.
- -Gas generator related: Compressor, compact pressure vessel, various gas generator etc.
- -Others: Oxygen capsule, gasoline measuring instrument, forklift etc.

#### Specification

Maximum pressure MPa[psi]	20 [2900.75]	Seal material	FKM(Standard)			
Pressure resistance MPa[psi]	30 [4351.13]	Operating temperature	Pursuant to seal material			
Body material	Brass / SUS316	Cracking pressure kPa[psi]	А	20~100 [2.90~14.50]	D	1010~2400 [146.49~348.09]
Pipe port	Rc1/4, Rc1/2		В	110~350 [15.95~50.76]	E	2410~4100 [349.54~594.65]
			С	360~1000 [52.21~145.04]		
Adjusting tool	Hex wrench 1/4=4mm[0.16in.] 1/2=8mm[0.31in.]					
Comment	<ul><li>If you need internal type, contact us.</li><li>Tool for control is not attached.</li></ul>					





Size


Pipe port (Two way)

HEX (Opposite side)

Pipe port(R)	А	HEX (Opposite side)	CV (Reference)
1 /4	<41.0> [1.61]	<14.0> [0.55]	<0.35>
1 /2	<65.0> [2.56]	<23.0> [0.91]	<1.25>

Flow

### Model designation



#### [Caution]

If you request for cracking pressure, please write cracking pressure after spring code by <kPa[psi]>. (Air pressure is not marked on body.)


Example) FCAMB2V-B-<u>300</u> 300kPa[43.51psi]

si] (Minimum setting pressure 10kPa[1.45])

If you have no request, pressure is set minimum range.



#### Adjustment method



- 1) Turn a fixed nut counterclockwise and loosen it, with a hexagon wrench.
- 2) Insert a hexagon wrench to pressure control nut and coordinate cracking pressure.

Clockwise direction: Higher Counterclockwise direction: Lower

- 3) Pull back a hexagon wrench to the bottom of the fixed nut and turn it clockwise and lock it.
- 4) Please confirm cracking pressure.



#### Contact us

Control Equipment Head office:TOC Ariake East Tower 10F, 3-5-7 Ariake, Koto-ku, Tokyo, Japan 135-0063 TEL +81-3-3527-8573 E-mail: seigyo.toiawase.en@fc.fujikura.co.jp URL:https://www.fujikura-control.com/